

DISFIS™



Quaternary Ammonium Compound Based Surface and Environmental Disinfectant





3rd Generation Quaternary Ammonium Compound

Active Ingredients	
Alkyl (60% C14, 30% C16, 5% C12, 5% C18) Dimethyl Benzyl Ammonium Chloride	2.37%
Alkyl (68% C12, 32% C14) Dimethyl Ethylbenzyl Ammonium Chloride	2.37%
Inert Ingredient	95.26%
Total	100%

Disfis is a balanced, stabilized blend of 3rd generation twin chain quaternary ammonium compounds. Disfis is recommended for use as a hard surface disinfectant in the hospitals, nursing homes, and various types of medical facilities. It delivers 99.99% kill of more than 148 types of different pathogens including HIV, HBV, HCV, polio, H1N1, H5N1, etc. with no evidence of resistance, eliminating the need to rotate disinfectants to avoid resistance build up.

Areas of Application			
Operation Theatre	Endoscopy	Emergency	ICU
Labour Room	ICCU	Cath Lab.	Dialysis Unit
SICU	Burn Unit	Microbiology	Blood Banks
Dental Clinics	Isolation Wards	NICU	Laboratory, etc.

Critical Area Dilution - 1:64

1.5% v/v solution of Disfis in DM water. Apply the solution with a cloth, mop, sponge, hand pump trigger sprayer or other mechanical sprayer allowing contact time of 10 minutes.

Other Area Dilution – 1:128

0.75% v/v solution of Disfis in DM water. Apply the solution with a cloth, mop, sponge, hand pump trigger sprayer or other mechanical sprayer allowing contact time of 10 minutes.

Fogging Dilution – 1:64

1.5% v/v solution of Disfis for every 1000 cu. ft. in high risk areas like OT, ICU, ICCU, NICU, Cath Lab, AKD, etc. Treated surfaces must remain wet for 1 hour.

Mildewstat – 1:64

Thoroughly clean surfaces prior to treatment. To control mold and mildew on pre-cleaned, hard, non-porous surfaces (such as floors, walls, table tops) add 1.5% v/v solution of Disfis in DM water. Apply the solution with a cloth, mop, or sponge making sure to wet all surfaces completely. Let air dry. Prepare fresh solution for each use. Repeat application at weekly intervals or when mildew growth reappears.

Fungicide – 1:64

1.5% v/v solution of Disfis is effective against the pathogenic fungus.



**Pack Size
1000 mL**

A Division of Tulip Diagnostics (P) Ltd.



Applying Science In Disinfection

Gitanjali, Tulip Block, Dr. Antonio do Rego Bagh,
Alto Santacruz, Bambolim Complex Post Office,
Goa - 403 202, INDIA.

Tel.: +91 832 2458546-50 Fax : +91 832 2458544

E-mail : sales@tulipgroup.com Website : www.tulipgroup.com